MANNAR THIRUMALAI NAICKER COLLEGE PASUMALAI, MADURAI - 625004

DEPARTMENT OF INFORMATION TECHNOLOGY

COMPUTER NETWORKS



Computer Networks

Syllabus

Unit I

Introduction: Data Communications – Networks – Protocols and Standards – Network Models: Layered Tasks – The OSI Model – Layers in the OSI Model – TCP/IP protocol suite.

Unit II

Physical Layer: Transmission Media: Guided media – Unguided media :Wireless - Wireless WANs: Cellular Telephone and Satellite Networks: Cellular Telephony – Satellite Networks.

Unit III

Data Link Layer: Error Detection and Correction: Introduction – Block Coding – Linear Block Codes – Cyclic Codes – Checksum –Data Link Control: Framing – Flow Control and Error Control – Protocols – Noiseless Channels–Noisy Channels

Unit IV Network Layer: Delivery, Forwarding and Routing: Delivery – Forwarding – Multicast Routing Protocols–Congestion Control and Quality of Service: Data Traffic – Congestion – Congestion Control – Quality of Service.

Unit V Application Layer:Domain Name System-DOMAIN NAME SPACE -DNS in the Internet-Remote Logging, Electronic Mail, and File Transfer: Electronic Mail-File TransferWWW and HTTP:Architecture-Web Documents-HTTP.


Text Book: 1.BehrouzA.Forouzan, Data Communications and Networking, Tata McGraw Hill Education Private Limited, New Delhi, Fourth Edition, Eighteenth reprint 2010

UNIT -I Introduction to Computer Networks

1.1 Data Communication: When we communicate, we are sharing information. This sharing can be local or remote. Between individuals, local communication usually occurs face to face, while remote communication takes place over distance.

1.1.1 Components:

A data communications system has five components.



1. Message. The message is the information (data) to be communicated. Popular forms of information include text, numbers, pictures, audio, and video.

2. Sender. The sender is the device that sends the data message. It can be a computer, workstation, telephone handset, video camera, and so on.

3. Receiver. The receiver is the device that receives the message. It can be a computer, workstation, telephone handset, television, and so on.

4. Transmission medium. The transmission medium is the physical path by which a message travels from sender to receiver. Some examples of transmission media include twisted-pair wire, coaxial cable, fiber-optic cable, and radio waves

5. Protocol. A protocol is a set of rules that govern data communications. It represents an agreement between the communicating devices. Without a protocol, two devices may be connected

but not communicating, just as a person speaking French cannot be understood by a person who speaks only Japanese.

1.1.2 Data Representation:

Information today comes in different forms such as text, numbers, images, audio, and video. *Text:*

In data communications, text is represented as a bit pattern, a sequence of bits (Os or Is). Different sets of bit patterns have been designed to represent text symbols. Each set is called a code, and the process of representing symbols is called coding. Today, the prevalent coding system is called Unicode, which uses 32 bits to represent a symbol or character used in any language in the world. The American Standard Code for Information Interchange (ASCII), developed some decades ago in the United States, now constitutes the first 127 characters in Unicode and is also referred to as Basic Latin.

Numbers:

Numbers are also represented by bit patterns. However, a code such as ASCII is not used to represent numbers; the number is directly converted to a binary number to simplify mathematical operations. Appendix B discusses several different numbering systems.

Images:

Images are also represented by bit patterns. In its simplest form, an image is composed of a matrix of pixels (picture elements), where each pixel is a small dot. The size of the pixel depends on the *resolution*. For example, an image can be divided into 1000 pixels or 10,000 pixels. In the second case, there is a better representation of the image (better resolution), but more memory is needed to store the image. After an image is divided into pixels, each pixel is assigned a bit pattern. The size and the value of the pattern depend on the image. For an image made of only blackand- white dots (e.g., a chessboard), a I-bit pattern is enough to represent a pixel. If an image is not made of pure white and pure black pixels, you can increase the size of the bit patterns. A black pixel can be represented by 00, a dark gray pixel by 01, a light gray pixel by 10, and a white pixel by 11. There are several methods to represent color images. One method is called RGB, so called because each color is made of a combination of three primary colors: *red*, green, and blue. The intensity of each color is measured, and a bit pattern is assigned to it.

Another method is called YCM, in which a color is made of a combination of three other primary colors: yellow, cyan, and magenta.

Audio:


Audio refers to the recording or broadcasting of sound or music. Audio is by nature different from text, numbers, or images. It is continuous, not discrete. Even when we use a microphone to change voice or music to an electric signal, we create a continuous signal. In Chapters 4 and 5, we learn how to change sound or music to a digital or an analog signal.

Video:


Video refers to the recording or broadcasting of a picture or movie. Video can either be produced as a continuous entity (e.g., by a TV camera), or it can be a combination of images, each a discrete entity, arranged to convey the idea of motion. Again we can change video to a digital or an analog signal.

1.1.3 Data Flow


Communication between two devices can be simplex, half-duplex, or full-duplex as shown in Figure



a. Simplex



b. Half-duplex




c. Full·duplex

Transmission modes


- The way in which data is transmitted from one device to another device is known as **transmission mode**.
- \circ $\;$ The transmission mode is also known as the communication mode.
- Each communication channel has a direction associated with it, and transmission media provide the direction. Therefore, the transmission mode is also known as a directional mode.
- The transmission mode is defined in the physical layer.

The Transmission mode is divided into three categories:



• Full-duplex mode

Simplex mode



Simplex mode, the communication is unidirectional, i.e., the data flow in one direction.


- A device can only send the data but cannot receive it or it can receive the data but cannot send the data.
- This transmission mode is not very popular as mainly communications require the two-way exchange of data. The simplex mode is used in the business field as in sales that do not require any corresponding reply. The radio station is a simplex channel as it transmits the signal to the listeners but never allows them to transmit back.
- Keyboard and Monitor are the examples of the simplex mode as a keyboard can only accept the data from the user and monitor can only be used to display the data on the screen.
- The main advantage of the simplex mode is that the full capacity of the communication channel can be utilized during transmission.

Advantage of Simplex mode:

• In simplex mode, the station can utilize the entire bandwidth of the communication channel, so that more data can be transmitted at a time.

Disadvantage of Simplex mode:

• Communication is unidirectional, so it has no inter-communication between devices.



Half-Duplex mode

duplex channel, direction can be reversed, i.e., the station can transmit and receive the data as well.


o In a Half-

- \circ Messages flow in both the directions, but not at the same time. \circ The entire bandwidth of the communication channel is utilized in one direction at a time.
- In half-duplex mode, it is possible to perform the error detection, and if any error occurs, then the receiver requests the sender to retransmit the data.
- A **Walkie-talkie** is an example of the Half-duplex mode. In Walkie-talkie, one party speaks, and another party listens. After a pause, the other speaks and first party listens. Speaking simultaneously will create the distorted sound which cannot be understood.

Advantage of Half-duplex mode: • In half-duplex mode, both the devices can send and receive the data and also can utilize the entire bandwidth of the communication channel during the transmission of data.

Disadvantage of Half-Duplex mode: • In half-duplex mode, when one device is sending the data, then another has to wait, this causes the delay in sending the data at the right time.







duplex mode, the communication is bi-directional, i.e., the data flow in both the directions.

- Both the stations can send and receive the message simultaneously.
- Full-duplex mode has two simplex channels. One channel has traffic moving in one direction, and another channel has traffic flowing in the opposite direction.
- The Full-duplex mode is the fastest mode of communication between devices.
- The most common example of the full-duplex mode is a telephone network. When two people are communicating with each other by a telephone line, both can talk and listen at the same time.

Advantage of Full-duplex mode:

 \circ $\,$ Both the stations can send and receive the data at the same time.

Disadvantage of Full-duplex mode: • If there is no dedicated path exists between the devices, then the capacity of the communication channel is divided into two parts.

1.2 NETWORKS

A network is a set of devices (often referred to as *nodes*) connected by communication links. A node can be a computer, printer, or any other device capable of sending and/or receiving data generated by other nodes on the network.

1.2.1 Distributed Processing

Most networks use distributed processing, in which a task is divided among multiple computers. Instead of one single large machine being responsible for all aspects of a process, separate computers (usually a personal computer or workstation) handle a subset.

1.2.2 Network Criteria

A network must be able to meet a certain number of criteria. The most important of these are performance, reliability, and security.

Performance:

Performance can be measured in many ways, including transit time and response time.Transit time is the amount of time required for a message to travel from one device to another. Response time is the elapsed time between an inquiry and a response. The performance of a network depends on a number of factors, including the number of users, the type of transmission medium, the capabilities of the connected hardware, and the efficiency of the software. Performance is often evaluated by two networking metrics: throughput and delay. We often need more throughput and less delay. However, these two criteria are often contradictory. If we try to send more data to the network, we may increase throughput but we increase the delay because of traffic congestion in the network.

Reliability:

In addition to accuracy of delivery, network reliability is measured by the frequency of failure, the time it takes a link to recover from a failure, and the network's robustness in a catastrophe.

Security:

Network security issues include protecting data from unauthorized access, protecting data from damage and development, and implementing policies and procedures for recovery from breaches and data losses.

1.2.3 Physical Structures:

Type of Connection


A network is two or more devices connected through links. A link is a communications pathway that transfers data from one device to another. For visualization purposes, it is simplest to imagine any link as a line drawn between two points. For communication to occur, two devices must be connected in some way to the same link at the same time. There are two possible types of connections: point-to-point and multipoint.

Point-to-Point

A point-to-point connection provides a dedicated link between two devices. The entire capacity of the link is reserved for transmission between those two devices. Most point-to- point connections use an actual length of wire or cable to connect the two ends, but other options, such as microwave or satellite links, are also possible. When you change television channels by infrared remote control, you are establishing a point-to-point connection between the remote control and the television's control system.

Multipoint

A multipoint (also called multidrop) connection is one in which more than two specific devices share a single link. In a multipoint environment, the capacity of the channel is shared, either spatially or temporally. If several devices can use the link simultaneously, it is a *spatially shared* connection. If users must take turns, it is a *timeshared* connection.




b. Multipoint

What is Topology?


Topology defines the structure of the network of how all the components are interconnected to each other. There are two types of topology: physical and logical topology.

Physical topology is the geometric representation of all the nodes in a network.



Bus Topology

0



- The bus topology is designed in such a way that all the stations are connected through a single cable known as a backbone cable.
- Each node is either connected to the backbone cable by drop cable or directly connected to the backbone cable.
 When a node wants to send a message over the network, it puts a message over the network. All the stations available in the network will receive the message whether it has been addressed or not.
- The bus topology is mainly used in 802.3 (ethernet) and 802.4 standard networks. The configuration of a bus topology is quite simpler as compared to other topologies.
- The backbone cable is considered as a **"single lane"** through which the message is broadcast to all the stations.
- The most common access method of the bus topologies is **CSMA** (Carrier Sense Multiple Access).

CSMA: It is a media access control used to control the data flow so that data integrity is maintained, i.e., the packets do not get lost. There are two alternative ways of handling the problems that occur when two nodes send the messages simultaneously.

- **CSMA CD:** CSMA CD (**Collision detection**) is an access method used to detect the collision. Once the collision is detected, the sender will stop transmitting the data. Therefore, it works on "**recovery after the collision**".
- **CSMA CA: CSMA CA (Collision Avoidance)** is an access method used to avoid the collision by checking whether the transmission media is busy or not. If busy, then the sender waits until the media becomes idle. This technique effectively reduces the possibility of the collision. It does not work on "recovery after the collision".

Advantages of Bus topology: • Low-cost cable: In bus topology, nodes are directly connected to the cable without passing through a hub. Therefore, the initial cost of installation is low.

- **Moderate data speeds:** Coaxial or twisted pair cables are mainly used in bus-based networks that support upto 10 Mbps.
- **Familiar technology:** Bus topology is a familiar technology as the installation and troubleshooting techniques are well known, and hardware components are easily available.
- Limited failure: A failure in one node will not have any effect on other nodes.

Disadvantages of Bus topology:

• Extensive cabling: A bus topology is quite simpler, but still it requires a lot of cabling.

- **Difficult troubleshooting:** It requires specialized test equipment to determine the cable faults. If any fault occurs in the cable, then it would disrupt the communication for all the nodes.
- **Signal interference:** If two nodes send the messages simultaneously, then the signals of both the nodes collide with each other.
- **Reconfiguration difficult:** Adding new devices to the network would slow down the network.
- Attenuation: Attenuation is a loss of signal leads to communication issues. Repeaters are used to regenerate the signal.

Ring Topology



- Ring topology is like a bus topology, but with connected ends.
- The node that receives the message from the previous computer will retransmit to the next node.
- $\circ~$ The data flows in one direction, i.e., it is unidirectional. $\circ~$ The data flows in a single loop continuously known as an endless loop.
- It has no terminated ends, i.e., each node is connected to other node and having no termination point.
- The data in a ring topology flow in a clockwise direction.
- The most common access method of the ring topology is **token passing**.
- **Token passing:** It is a network access method in which token is passed from one node to another node.

• **Token:** It is a frame that circulates around the network.

Working of Token passing • A token moves around the network, and it is passed from computer to computer until it reaches the destination.

- The sender modifies the token by putting the address along with the data.
- The data is passed from one device to another device until the destination address matches. Once the token received by the destination device, then it sends the acknowledgment to the sender.
- In a ring topology, a token is used as a carrier.

Advantages of Ring topology:


Network Management: Faulty devices can be removed from the network without bringing the network down.

- **Product availability:** Many hardware and software tools for network operation and monitoring are available.
- **Cost:** Twisted pair cabling is inexpensive and easily available. Therefore, the installation cost is very low.
- **Reliable:** It is a more reliable network because the communication system is not dependent on the single host computer.

Disadvantages of Ring topology:

- **Difficult troubleshooting:** It requires specialized test equipment to determine the cable faults. If any fault occurs in the cable, then it would disrupt the communication for all the nodes.
- Failure: The breakdown in one station leads to the failure of the overall network.
- **Reconfiguration difficult:** Adding new devices to the network would slow down the network.
- **Delay:** Communication delay is directly proportional to the number of nodes. Adding new devices increases the communication delay.

Star Topology




- Star topology is an arrangement of the network in which every node is connected to the central hub, switch or a central computer.
- The central computer is known as a **server**, and the peripheral devices attached to the server are known as **clients**.
- Coaxial cable or RJ-45 cables are used to connect the computers.
 Hubs or Switches are mainly used as connection devices in a physical star topology.
 Star topology is the most popular topology in network implementation.
- Advantages of Star topology o Efficient troubleshooting: Troubleshooting is quite efficient in a star topology as compared to bus topology. In a bus topology, the manager has to inspect the kilometers of cable. In a star topology, all the stations are connected to the centralized network. Therefore, the network administrator has to go to the single station to troubleshoot the problem.
 - **Network control:** Complex network control features can be easily implemented in the star topology. Any changes made in the star topology are automatically accommodated.
 - **Limited failure:** As each station is connected to the central hub with its own cable, therefore failure in one cable will not affect the entire network.
 - Familiar technology: Star topology is a familiar technology as its tools are cost-effective.
 - **Easily expandable:** It is easily expandable as new stations can be added to the open ports on the hub. **Cost effective:** Star topology networks are cost-effective as it uses inexpensive coaxial cable.
 - **High data speeds:** It supports a bandwidth of approx 100Mbps. Ethernet 100BaseT is one of the most popular Star topology networks.

Disadvantages of Star topology • A Central point of failure: If the central hub or switch goes down, then all the connected nodes will not be able to communicate with each other.

• **Cable:** Sometimes cable routing becomes difficult when a significant amount of routing is required.

Tree topology



- \circ Tree topology combines the characteristics of bus topology and star topology.
- A tree topology is a type of structure in which all the computers are connected with each other in hierarchical fashion. The top-most node in tree topology is known as a root node, and all other nodes are the descendants of the root node.

There is only one path exists between two nodes for the data transmission. Thus, it forms a parent-child hierarchy.

Advantages of Tree topology • Support for broadband transmission: Tree topology is mainly used to provide broadband transmission, i.e., signals are sent over long distances without being attenuated.


- **Easily expandable:** We can add the new device to the existing network. Therefore, we can say that tree topology is easily expandable.
- **Easily manageable:** In tree topology, the whole network is divided into segments known as star networks which can be easily managed and maintained.
- **Error detection:** Error detection and error correction are very easy in a tree topology. **Limited failure:** The breakdown in one station does not affect the entire network.
- **Point-to-point wiring:** It has point-to-point wiring for individual segments.

Disadvantages of Tree topology • **Difficult troubleshooting:** If any fault occurs in the node, then it becomes difficult to troubleshoot the problem.

• **High cost:** Devices required for broadband transmission are very costly.

- **Failure:** A tree topology mainly relies on main bus cable and failure in main bus cable will damage the overall network.
- **Reconfiguration difficult:** If new devices are added, then it becomes difficult to reconfigure.

Mesh topology



- Mesh technology is an arrangement of the network in which computers are interconnected with each other through various redundant connections.
 - There are multiple paths from one computer to another computer.
 - It does not contain the switch, hub or any central computer which acts as a central point of communication.


The Internet is an example of the mesh topology.

- Mesh topology is mainly used for WAN implementations where communication failures are a critical concern.
- Mesh topology is mainly used for wireless networks.
- Mesh topology can be formed by using the formula: Number of cables = $(n^{*}(n-1))/2$;

Where n is the number of nodes that represents the network.

Mesh topology is divided into two categories:

- Fully connected mesh topology
- Partially connected mesh topology



- **Full Mesh Topology:** In a full mesh topology, each computer is connected to all the computers available in the network.
- **Partial Mesh Topology:** In a partial mesh topology, not all but certain computers are connected to those computers with which they communicate frequently.

Advantages of Mesh topology:

Reliable: The mesh topology networks are very reliable as if any link breakdown will not affect the communication between connected computers.

Fast Communication: Communication is very fast between the nodes.


Easier Reconfiguration: Adding new devices would not disrupt the communication between other devices.

Disadvantages of Mesh topology \circ **Cost:** A mesh topology contains a large number of connected devices such as a router and more transmission media than other topologies.

• **Management:** Mesh topology networks are very large and very difficult to maintain and manage. If the network is not monitored carefully, then the communication link failure goes undetected.

Efficiency: In this topology, redundant connections are high that reduces the efficiency of the network.

Hybrid Topology



- The combination of various different topologies is known as **Hybrid topology**. A Hybrid topology is a connection between different links and nodes to transfer the data.
- When two or more different topologies are combined together is termed as Hybrid topology and if similar topologies are connected with each other will not result in Hybrid topology. For example, if there exist a ring topology in one branch of ICICI bank and bus topology in another branch of ICICI bank, connecting these two topologies will result in Hybrid topology.

Advantages of Hybrid Topology o **Reliable:** If a fault occurs in any part of the network will not affect the functioning of the rest of the network.

- **Scalable:** Size of the network can be easily expanded by adding new devices without affecting the functionality of the existing network.
- **Flexible:** This topology is very flexible as it can be designed according to the requirements of the organization.

Effective: Hybrid topology is very effective as it can be designed in such a way that the strength of the network is maximized and weakness of the network is minimized.

Disadvantages of Hybrid topology • **Complex design:** The major drawback of the Hybrid topology is the design of the Hybrid network. It is very difficult to design the architecture of the Hybrid network.


- **Costly Hub:** The Hubs used in the Hybrid topology are very expensive as these hubs are different from usual Hubs used in other topologies.
- **Costly infrastructure:** The infrastructure cost is very high as a hybrid network requires a lot of cabling, network devices, etc.

1.2.4 Categories of Networks

Computer Network Types

A computer network is a group of computers linked to each other that enables the computer to communicate with another computer and share their resources, data, and applications.

A computer network can be categorized by their size. A **computer network** is mainly of **four types**:



• WAN(Wide Area Network)

LAN(Local Area Network) o Local Area Network is a group of computers connected to each other in a small area such as building, office.

LAN is used for connecting two or more personal computers through a communication medium such as twisted pair, coaxial cable, etc.

- It is less costly as it is built with inexpensive hardware such as hubs, network adapters, and ethernet cables.
- The data is transferred at an extremely faster rate in Local Area Network.
- Local Area Network provides higher security.




PAN(Personal Area Network) \circ Personal Area Network is a network arranged within an individual person, typically within a range of 10 meters.

- Personal Area Network is used for connecting the computer devices of personal use is known as Personal Area Network.
- **Thomas Zimmerman** was the first research scientist to bring the idea of the Personal Area Network.
- Personal Area Network covers an area of **30 feet**.
- Personal computer devices that are used to develop the personal area network are the laptop, mobile phones, media player and play stations.



There are two types of Personal Area Network:



- Wired Personal Area Network
- o Wireless Personal Area Network

Wireless Personal Area Network: Wireless Personal Area Network is developed by simply using wireless technologies such as WiFi, Bluetooth. It is a low range network.

Wired Personal Area Network: Wired Personal Area Network is created by using the USB.


Examples Of Personal Area Network:

Body Area Network: Body Area Network is a network that moves with a person. For example, a mobile network moves with a person. Suppose a person establishes a network connection and then creates a connection with another device to share the information.
 Offline Network: An offline network can be created inside the home, so it is also known as a home network. A home network is designed to integrate the devices such as printers, computer, television but they are not connected to the internet.

• **Small Home Office:** It is used to connect a variety of devices to the internet and to a corporate network using a VPN

MAN(Metropolitan Area Network) \circ A metropolitan area network is a network that covers a larger geographic area by interconnecting a different LAN to form a larger network. Government agencies use MAN to connect to the citizens and private industries.

- In MAN, various LANs are connected to each other through a telephone exchange line.
- The most widely used protocols in MAN are RS-232, Frame Relay, ATM, ISDN, OC-3, ADSL, etc.
- It has a higher range than Local Area Network(LAN).




Uses Of Metropolitan Area Network:

- MAN is used in communication between the banks in a city.
 It can be used in an Airline Reservation.
 It can be used in a college within a city.
- It can also be used for communication in the military.

WAN(Wide Area Network) \circ A Wide Area Network is a network that extends over a large geographical area such as states or countries.

- A Wide Area Network is quite bigger network than the LAN.
- A Wide Area Network is not limited to a single location, but it spans over a large geographical area through a telephone line, fibre optic cable or satellite links.
- \circ The internet is one of the biggest WAN in the world. \circ A Wide Area Network is widely used in the field of Business, government, and education.



Examples Of Wide Area Network:

- Mobile Broadband: A 4G network is widely used across a region or country.
- **Last mile:** A telecom company is used to provide the internet services to the customers in hundreds of cities by connecting their home with fiber.
- **Private network:** A bank provides a private network that connects the 44 offices. This network is made by using the telephone leased line provided by the telecom company.

Advantages Of Wide Area Network:

Following are the advantages of the Wide Area Network:

- **Geographical area:** A Wide Area Network provides a large geographical area. Suppose if the branch of our office is in a different city then we can connect with them through WAN. The internet provides a leased line through which we can connect with another branch.
- **Centralized data:** In case of WAN network, data is centralized. Therefore, we do not need to buy the emails, files or back up servers.
- **Get updated files:** Software companies work on the live server. Therefore, the programmers get the updated files within seconds.
- **Exchange messages:** In a WAN network, messages are transmitted fast. The web application like Facebook, Whatsapp, Skype allows you to communicate with friends.
- **Sharing of software and resources:** In WAN network, we can share the software and other resources like a hard drive, RAM.
- Global business: We can do the business over the internet globally.
 High bandwidth: If we use the leased lines for our company then this gives the high bandwidth. The high bandwidth increases the data transfer rate which in turn increases the productivity of our company.

Disadvantages of Wide Area Network:

The following are the disadvantages of the Wide Area Network:

- Security issue: A WAN network has more security issues as compared to LAN and MAN network as all the technologies are combined together that creates the security problem.
 Needs Firewall & antivirus software: The data is transferred on the internet which can be changed or hacked by the hackers, so the firewall needs to be used. Some people can inject the virus in our system so antivirus is needed to protect from such a virus.
- **High Setup cost:** An installation cost of the WAN network is high as it involves the purchasing of routers, switches.
- Troubleshooting problems: It covers a large area so fixing the problem is difficult.
- Internetwork \circ An internetwork is defined as two or more computer network LANs or WAN or computer network segments are connected using devices, and they are configured by a local addressing scheme. This process is known as **internetworking**.
 - An interconnection between public, private, commercial, industrial, or government computer networks can also be defined as **internetworking**.
 - An internetworking uses the **internet protocol**.
 - The reference model used for internetworking is **Open System Interconnection(OSI)**.

Types Of Internetwork:


1. **Extranet:** An extranet is a communication network based on the internet protocol such as **Transmission Control protocol** and **internet protocol**. It is used for information sharing. The access to the extranet is restricted to only those users who have login credentials. An extranet is the lowest level of internetworking. It can be categorized as **MAN**, **WAN** or other computer networks. An extranet cannot have a single **LAN**, atleast it must have one connection to the external network.

2. **Intranet:** An intranet is a private network based on the internet protocol such as **Transmission Control protocol** and **internet protocol**. An intranet belongs to an organization which is only accessible by the **organization's employee** or members. The main aim of the intranet is to share the information and resources among the organization employees. An intranet provides the facility to work in groups and for teleconferences.

Intranet advantages:

- **Communication:** It provides a cheap and easy communication. An employee of the organization can communicate with another employee through email, chat.
- **Time-saving:** Information on the intranet is shared in real time, so it is time-saving.
- **Collaboration:** Collaboration is one of the most important advantage of the intranet. The information is distributed among the employees of the organization and can only be accessed by the authorized user.
- **Platform independency:** It is a neutral architecture as the computer can be connected to another device with different architecture.
- **Cost effective:** People can see the data and documents by using the browser and distributes the duplicate copies over the intranet. This leads to a reduction in the cost.


The Internet Today



The Internet has come a long way since the 1960s. The Internet today is not a simple hierarchical structure. It is made up of many wide- and local-area networks joined by

0

connecting devices and switching stations. It is difficult to give an accurate representation of the Internet because it is continually changing-new networks are being added, existing networks are adding addresses, and networks of defunct companies are being removed. Today most end users who want Internet connection use the services of Internet service providers (ISPs). There are international service providers, national service providers, regional service providers, and local service providers. The Internet today is run by private companies, not the government. Figure 1.13 shows a conceptual (not geographic) view of the Internet.



a. Structure of a national ISP

International Internet Service Providers:

At the top of the hierarchy are the international service providers that connect nations together.

National Internet Service Providers:

The national Internet service providers are backbone networks created and maintained by specialized companies. There are many national ISPs operating in North America; some of the most well known are SprintLink, PSINet, UUNet Technology, AGIS, and internet Mel. To provide connectivity between the end users, these backbone networks are connected by complex switching stations (normally run by a third party) called network access points (NAPs). Some national ISP networks are also connected to one another by private switching stations called *peering points*. These normally operate at a high data rate (up to 600 Mbps).

Regional Internet Service Providers:

Regional internet service providers or regional ISPs are smaller ISPs that are connected to one or more national ISPs. They are at the third level of the hierarchy with a smaller data rate. *Local Internet Service Providers:*

Local Internet service providers provide direct service to the end users. The local ISPs can be connected to regional ISPs or directly to national ISPs. Most end users are connected to the local ISPs. Note that in this sense, a local ISP can be a company that just provides Internet services, a corporation with a network that supplies services to its own employees, or a nonprofit organization, such as a college or a university, that runs its own network. Each of these local ISPs can be connected to a regional or national service provider.

1.3 PROTOCOLS AND STANDARDS

Protocols

In computer networks, communication occurs between entities in different systems. An **entity** is anything capable of sending or receiving information. However, two entities cannot simply send bit streams to each other and expect to be understood. For communication to occur, the entities must agree on a **protocol**.

A **protocol** is a set of rules that governs data communication. A protocol defines what is communicated, how it is communicated and what is communicated. The Key elements of a protocol are syntax, semantics and timing.

- **Syntax.** Syntax refers to the structure or format of the data, meaning the order in which they are presented. For example, a simple protocol might expect the first 8 bits of data to be the address of the sender, the second 8 bits to the address of the receiver, and the rest of the stream to the message itself.
- Semantics. Semantics refers to the meaning of each section of bits. How is a particular pattern to be interpreted, and what action is to be taken based on that interpretation? For example, does an address identify the route to be taken or the final destination of the message?
- **Timing.** Timing refers to two characteristics: when data should be sent and how fast it can be sent. For example, if a sender produces data at 100 Megabits per second (Mbps) but the receiver can process data at only 1 Mbps, the transmission will overload the receiver and data will be largely lost.

Standards

Standards are essential in creating and maintaining an open and competitive market for equipment manufacturers and also in guaranteeing national and international interoperability of data and telecommunications technology and processes. They provide guidelines to manufacturers, vendors, government agencies, and other service providers to ensure the kind of interconnectivity necessary in today's marketplace and in international communication.

Data communication standards fall into two categories: *de facto* (meaning "by fact" or "by convention") and *de jure* (meaning "by law" and "by regulation").

- **De facto.** Standards that have not been approved by an organized body but have been adopted as standards through widespread use are **de facto standards.** De facto standards are often established originally by manufacturers that seek to define the functionality of a new product or technology.
 - **De jure. De jure standards** are those that have been legislated by an oficially recognized body.

Standards and Organizations standards are developed through cooperation of standards creation committees, forums and government regulatory agencies. Some of the standards establishment Organizations are:

- International Standards Organisation (ISO) <u>http://www.iso.org/</u>
- International Telecommunications Union-Telecommunication Standards Sector (ITU- T). <u>http://www.itu.int/ITU-T</u>
- American National Standard Institute (ANSI).
- Institute of Electrical and Electronics Engineers (IEEE). <u>http://www.ieee.gov/</u>
- Electronic Industries Association (EIA).

Forums

Telecommunications technology development is moving faster than the ability of standards committee to ratify standards. Standards committees are procedural bodies and by nature slow moving. to accommodate the need fro working models and agreements and to facilitate the standardization process, many special-interest groups have developed *forums* made up of representatives from interested corporations. The forums work with universities and users to test, evaluate and standardize new technologies. By concentrating their efforts on a particular technology, the forums are able to speed acceptance and use of those technologies in the telecommunications community. The forums present their conclusions to the standards bodies.

Some important forums for the telecommunications industry include the following:

- **Frame Relay Forum.** The Frame Relay Forum was formed by digital equipment Corporation, Northern Telecom, Cisco, and StrataCom to promote the acceptance and implementation of frame relay. Today, it has around 40 members representing North America, Europe, and the Pacific rim. Issues under Review include flow control. encapsulation, translation, and multicasting. the forum's results are submitted to the ISO.
- **ATM Forum.** <u>http://www.atmforum.com/</u> The ATM Forum provides acceptance and use of Asynchronous Transfer Mode (ATM) technology. The ATM Forum is made up of Customer Premises Equipment (e.g., PBX systems) vendors and Central Office (e.g.,

telephone exchange) providers. It is concerned with the standardization of service to ensure interoperability.


Regulatory Agencies


All communications technology is subject to regulation by government agencies such as Federal Communication Commission in the United States. The purpose of these agencies is to protect the public interest by regulating radio, television, and wire/cable communications.

• Federal Communications Commission (FCC). <u>http://www.fcc.gov/</u> The Federal Communications Commission (FCC) has authority over interstate and international commerce as it relates to communications.

1.4 LAYERED TASKS

We use the concept of layers in our daily life. As an example, let us consider two friends who communicate through postal maiL The process of sending a letter to a friend would be complex if there were no services available from the post office. Below Figure shows the steps in this task.





Sender, Receiver, and Carrier

In Figure we have a sender, a receiver, and a carrier that transports the letter. There is a hierarchy of tasks.

At the Sender Site

Let us first describe, in order, the activities that take place at the sender site.

• Higher layer. The sender writes the letter, inserts the letter in an envelope, writes the sender and receiver addresses, and drops the letter in a mailbox.

- o Middle layer. The letter is picked up by a letter carrier and delivered to the post office.
- o Lower layer. The letter is sorted at the post office; a carrier transports the letter.

On the Way: The letter is then on its way to the recipient. On the way to the recipient's local post office, the letter may actually go through a central office. In addition, it may be transported by truck, train, airplane, boat, or a combination of these.


At the Receiver Site o Lower layer. The carrier transports the letter to the post office. o Middle layer. The letter is sorted and delivered to the recipient's mailbox.

o Higher layer. The receiver picks up the letter, opens the envelope, and reads it.

OSI Model

- o OSI stands for **Open System Interconnection** is a reference model that describes how information from a <u>software</u> application in one <u>computer</u> moves through a physical medium to the software application in another computer.
- o OSI consists of seven layers, and each layer performs a particular network function.
- o OSI model was developed by the International Organization for Standardization (ISO) in 1984, and it is now considered as an architectural model for the inter-computer communications.
- o OSI model divides the whole task into seven smaller and manageable tasks. Each layer is assigned a particular task.
- o Each layer is self-contained, so that task assigned to each layer can be performed independently.

Characteristics of OSI Model:




- o The OSI model is divided into two layers: upper layers and lower layers.
- o The upper layer of the OSI model mainly deals with the application related issues, and they are implemented only in the software. The application layer is closest to the end user. Both the end user and the application layer interact with the software applications. An upper layer refers to the layer just above another layer.
- o The lower layer of the OSI model deals with the data transport issues. The data link layer and the physical layer are implemented in hardware and software. The physical layer is the lowest layer of the OSI model and is closest to the physical medium. The physical layer is mainly responsible for placing the information on the physical medium.


Functions of the OSI Layers

There are the seven OSI layers. Each layer has different functions. A list of seven layers are given below:

- 1. Physical Layer
- 2. Data-Link Layer
- 3. Network Layer
- 4. Transport Layer
- 5. Session Layer
- 6. Presentation Layer
- 7. Application Layer




Physical layer



- The main functionality of the physical layer is to transmit the individual bits from one node to another node.
- $\circ~$ It is the lowest layer of the OSI model. $\circ~$ It establishes, maintains and deactivates the physical connection.
- \circ It specifies the mechanical, electrical and procedural network interface specifications.

Functions of a Physical layer:


- **Line Configuration:** It defines the way how two or more devices can be connected physically.
- **Data Transmission:** It defines the transmission mode whether it is simplex, half-duplex or full-duplex mode between the two devices on the network.
- **Topology:** It defines the way how network devices are arranged.
- Signals: It determines the type of the signal used for transmitting the information.



- \circ This layer is responsible for the error-free transfer of data frames. \circ It defines the format of the data on the network. \circ It provides a reliable and efficient communication between two or more devices.
- It is mainly responsible for the unique identification of each device that resides on a local network.
- It contains two sub-layers:
- \circ Logical Link Control Layer \circ It is responsible for transferring the packets to the Network layer of the receiver that is receiving. \circ It identifies the address of the network layer protocol from the header.
- It also provides flow control.
- **Media Access Control Layer** A Media access control layer is a link between the Logical Link Control layer and the network's physical layer.
- It is used for transferring the packets over the network.
- Functions of the Data-link layer \circ **Framing:** The data link layer translates the physical's raw bit stream into packets known as Frames. The Data link layer adds the header and trailer to the frame. The header which is added to the frame contains the hardware destination and source address.

Header	Packet	Trailer	

- **Physical Addressing:** The Data link layer adds a header to the frame that contains a destination address. The frame is transmitted to the destination address mentioned in the header.
- **Flow Control:** Flow control is the main functionality of the Data-link layer. It is the technique through which the constant data rate is maintained on both the sides so that no data get corrupted. It ensures that the transmitting station such as a server with higher processing speed does not exceed the receiving station, with lower processing speed.
- **Error Control:** Error control is achieved by adding a calculated value CRC (Cyclic Redundancy Check) that is placed to the Data link layer's trailer which is added to the message frame before it is sent to the physical layer. If any error seems to occurr, then the receiver sends the acknowledgment for the retransmission of the corrupted frames.
- Access Control: When two or more devices are connected to the same communication channel, then the data link layer protocols are used to determine which device has control over the link at a given time.




- It is a layer 3 that manages device addressing, tracks the location of devices on the network.
- It determines the best path to move data from source to the destination based on the network conditions, the priority of service, and other factors.
- The Data link layer is responsible for routing and forwarding the packets.
- Routers are the layer 3 devices, they are specified in this layer and used to provide the routing services within an internetwork.
- The protocols used to route the network traffic are known as Network layer protocols. Examples of protocols are IP and Ipv6.

Functions of Network Layer: • **Internetworking:** An internetworking is the main responsibility of the network layer. It provides a logical connection between different devices.

- <u>Addressing</u>: A Network layer adds the source and destination address to the header of the frame. Addressing is used to identify the device on the internet.

 <u>Routing</u>: Routing is the major component of the network layer, and it determines the best optimal path out of the multiple paths from source to the destination.
- **Packetizing:** A Network Layer receives the packets from the upper layer and converts them into packets. This process is known as Packetizing. It is achieved by internet protocol (IP).



- The Transport layer is a Layer 4 ensures that messages are transmitted in the order in which they are sent and there is no duplication of data.
- The main responsibility of the transport layer is to transfer the data completely.
- It receives the data from the upper layer and converts them into smaller units known as segments.
- This layer can be termed as an end-to-end layer as it provides a point-to-point connection between source and destination to deliver the data reliably.

The two protocols used in this layer are:


- **Transmission Control Protocol** It is a standard protocol that allows the systems to communicate over the internet. It establishes and maintains a connection between hosts.
- When data is sent over the TCP connection, then the TCP protocol divides the data into smaller units known as segments. Each segment travels over the internet using multiple routes, and they arrive in different orders at the destination. The transmission control protocol reorders the packets in the correct order at the receiving end.
- User Datagram Protocol User Datagram Protocol is a transport layer protocol.
- It is an unreliable transport protocol as in this case receiver does not send any acknowledgment when the packet is received, the sender does not wait for any acknowledgment. Therefore, this makes a protocol unreliable.

Functions of Transport Layer:

• Service-point addressing: Computers run several programs simultaneously due to this reason, the transmission of data from source to the destination not only from one computer to another computer but also from one process to another process. The transport layer adds the header that contains the address known as a service-point address or port address. The responsibility of the network layer is to transmit the data from one computer to another computer and the responsibility of the transport layer is to transmit the message to the correct process.

Segmentation and reassembly: When the transport layer receives the message from the upper layer, it divides the message into multiple segments, and each segment is assigned with a sequence number that uniquely identifies each segment. When the message has arrived at the destination, then the transport layer reassembles the message based on their sequence numbers.

- **Connection control:** Transport layer provides two services Connection-oriented service and connectionless service. A connectionless service treats each segment as an individual packet, and they all travel in different routes to reach the destination. A connection-oriented service makes a connection with the transport layer at the destination machine before delivering the packets. In connection-oriented service, all the packets travel in the single route.
- **Flow control:** The transport layer also responsible for flow control but it is performed end-to-end rather than across a single link.
- **Error control:** The transport layer is also responsible for Error control. Error control is performed end-to-end rather than across the single link. The sender transport layer ensures that message reach at the destination without any error.




- It is a layer 3 in the OSI model.
- The Session layer is used to establish, maintain and synchronizes the interaction between communicating devices.

Functions of Session layer:

- **Dialog control:** Session layer acts as a dialog controller that creates a dialog between two processes or we can say that it allows the communication between two processes which can be either half-duplex or full-duplex.
- **Synchronization:** Session layer adds some checkpoints when transmitting the data in a sequence. If some error occurs in the middle of the transmission of data, then the transmission

will take place again from the checkpoint. This process is known as Synchronization and recovery.




- A Presentation layer is mainly concerned with the syntax and semantics of the information exchanged between the two systems.
- It acts as a data translator for a network.
- This layer is a part of the operating system that converts the data from one presentation format to another format.
- The Presentation layer is also known as the syntax layer.

Functions of Presentation layer:

- **Translation:** The processes in two systems exchange the information in the form of character strings, numbers and so on. Different computers use different encoding methods, the presentation layer handles the interoperability between the different encoding methods. It converts the data from sender-dependent format into a common format and changes the common format into receiver-dependent format at the receiving end.
- **Encryption:** Encryption is needed to maintain privacy. Encryption is a process of converting the sender-transmitted information into another form and sends the resulting message over the network.
- **Compression:** Data compression is a process of compressing the data, i.e., it reduces the number of bits to be transmitted. Data compression is very important in multimedia such as text, audio, video.

Application Layer



An application layer serves as a window for users and application processes to access network service.

- It handles issues such as network transparency, resource allocation, etc.

 An application layer is not an application, but it performs the application layer functions.
- This layer provides the network services to the end-users.

Functions of Application layer:


- **File transfer, access, and management (FTAM):** An application layer allows a user to access the files in a remote computer, to retrieve the files from a computer and to manage the files in a remote computer.
- Mail services: An application layer provides the facility for email forwarding and storage.
- Directory services: An application provides the distributed database sources and is used to provide that global information about various objects.

TCP/IP model

- \circ The TCP/IP model was developed prior to the OSI model. \circ The TCP/IP model is not exactly similar to the OSI model.
- The TCP/IP model consists of five layers: the application layer, transport layer, network layer, data link layer and physical layer.
- The first four layers provide physical standards, network interface, internetworking, and transport functions that correspond to the first four layers of the OSI model and these four layers are represented in TCP/IP model by a single layer called the application layer.
- TCP/IP is a hierarchical protocol made up of interactive modules, and each of them provides specific functionality.

Here, hierarchical means that each upper-layer protocol is supported by two or more lower-level protocols.

Functions of TCP/IP layers:



Network Access Layer o A network layer is the lowest layer

of the TCP/IP model.

- A network layer is the combination of the Physical layer and Data Link layer defined in the OSI reference model.
- It defines how the data should be sent physically through the network.
- This layer is mainly responsible for the transmission of the data between two devices on the same network.
- The functions carried out by this layer are encapsulating the IP datagram into frames transmitted by the network and mapping of IP addresses into physical addresses.
- The protocols used by this layer are ethernet, token ring, FDDI, X.25, frame relay.

Internet Layer o An internet layer is the second layer of the

TCP/IP model. \circ An internet layer is also known as the network layer.

• The main responsibility of the internet layer is to send the packets from any network, and they arrive at the destination irrespective of the route they take.

Following are the protocols used in this layer are:

IP Protocol: IP protocol is used in this layer, and it is the most significant part of the entire TCP/IP suite.

Following are the responsibilities of this protocol:

IP Addressing: This protocol implements logical host addresses known as IP addresses. The IP addresses are used by the internet and higher layers to identify the device and to provide internetwork routing.

- **Host-to-host communication:** It determines the path through which the data is to be transmitted.
- **Data Encapsulation and Formatting:** An IP protocol accepts the data from the transport layer protocol. An IP protocol ensures that the data is sent and received securely, it encapsulates the data into message known as IP datagram.
- **Fragmentation and Reassembly:** The limit imposed on the size of the IP datagram by data link layer protocol is known as Maximum Transmission unit (MTU). If the size of IP datagram is greater than the MTU unit, then the IP protocol splits the datagram into smaller units so that they can travel over the local network. Fragmentation can be done by the sender or intermediate router. At the receiver side, all the fragments are reassembled to form an original message.
- **Routing:** When IP datagram is sent over the same local network such as LAN, MAN, WAN, it is known as direct delivery. When source and destination are on the distant network, then the IP datagram is sent indirectly. This can be accomplished by routing the IP datagram through various devices such as routers.

ARP Protocol

- ARP stands for Address Resolution Protocol.
- ARP is a network layer protocol which is used to find the physical address from the IP address.
- The two terms are mainly associated with the ARP Protocol:
- **ARP request:** When a sender wants to know the physical address of the device, it broadcasts the ARP request to the network.
- **ARP reply:** Every device attached to the network will accept the ARP request and process the request, but only recipient recognize the IP address and sends back its physical address in the form of ARP reply. The recipient adds the physical address both to its cache memory and to the datagram header

ICMP Protocol

• **ICMP** stands for Internet Control Message Protocol.

- It is a mechanism used by the hosts or routers to send notifications regarding datagram problems back to the sender.
- A datagram travels from router-to-router until it reaches its destination. If a router is unable to route the data because of some unusual conditions such as disabled links, a device is on fire or network congestion, then the ICMP protocol is used to inform the sender that the datagram is undeliverable.
- An ICMP protocol mainly uses two terms:
- **ICMP Test:** ICMP Test is used to test whether the destination is reachable or not.
- **ICMP Reply:** ICMP Reply is used to check whether the destination device is responding or not.
- The core responsibility of the ICMP protocol is to report the problems, not correct them. The responsibility of the correction lies with the sender.
- ICMP can send the messages only to the source, but not to the intermediate routers because the IP datagram carries the addresses of the source and destination but not of the router that it is passed to.

Transport Layer

The transport layer is responsible for the reliability, flow control, and correction of data which is being sent over the network.

The two protocols used in the transport layer are **User Datagram protocol and Transmission control protocol**.

- \circ User Datagram Protocol (UDP) \circ It provides connectionless service and end-to-end delivery of transmission. \circ It is an unreliable protocol as it discovers the errors but not specify the error.
- User Datagram Protocol discovers the error, and ICMP protocol reports the error to the sender that user datagram has been damaged.
- UDP consists of the following fields:
 - **Source port address:** The source port address is the address of the application program that has created the message.

Destination port address: The destination port address is the address of the application program that receives the message.

Total length: It defines the total number of bytes of the user datagram in bytes. **Checksum:** The checksum is a 16-bit field used in error detection.

• UDP does not specify which packet is lost. UDP contains only checksum; it does not contain any ID of a data segment.

Variable			
8 bytes			
Header	Data		
Heade	er Format		
Source port address 16 bits	Destination port address 16 bits		
Total length 16 bits	Checksum 16 bits		

- \circ Transmission Control Protocol (TCP) \circ It provides a full transport layer services to applications.
- It creates a virtual circuit between the sender and receiver, and it is active for the duration of the transmission.
- TCP is a reliable protocol as it detects the error and retransmits the damaged frames. Therefore, it ensures all the segments must be received and acknowledged before the transmission is considered to be completed and a virtual circuit is discarded.
- At the sending end, TCP divides the whole message into smaller units known as segment, and each segment contains a sequence number which is required for reordering the frames to form an original message.
- At the receiving end, TCP collects all the segments and reorders them based on sequence numbers.

Application Layer o An application layer is the topmost layer in the

TCP/IP model. \circ It is responsible for handling high-level protocols, issues of

representation. \circ This layer allows the user to interact with the application.

- When one application layer protocol wants to communicate with another application layer, it forwards its data to the transport layer.
- There is an ambiguity occurs in the application layer. Every application cannot be placed inside the application layer except those who interact with the communication system. For example: text editor cannot be considered in application layer while web browser using **HTTP** protocol to interact with the network where **HTTP** protocol is an application layer protocol.